Schedule

[Fundamentals]

- 1. 4/15 Basic chemical and biochemical concepts
- 2. 4/22 Basic biophysical concepts
- 3. 4/29 Basic bioelectrochemical concepts1
- 4. 5/13 Basic bioelectrochemical concepts2

[Applications]

- 5. 5/20 Cancel (Homework1 and 2)
- 6. 5/27 Biosensors and bioelectronics1
- 7. 6/03 Cancel (Homework3 and 4)
- 8. 6/10 Student seminar
- 9. 6/17 Biosensors and bioelectronics2
- 10. 6/24 From bioelectronics (electron) to iontronics (ion) 1
- 11. 7/01 From bioelectronics (electron) to iontronics (ion)2
- 12. 7/8 Wearable applications1
- 13. 7/15 Wearable applications2
- 14. 7/22 Student seminar

Principle of electrochemistry

The relationship between <u>chemical reaction</u> and <u>electricity</u> (Conversion: chemical energy ≒ electrical energy)




1. Certain chemical reactions can create electricity. (Galvanic cell)




2. Electricity can make certain chemical reactions. (Electrolytic cell)







Conductivity (σ)




Ionic conductivity (σ)



Ionic conductivity (σ)







 $\Lambda \neq \frac{\sigma}{c}$


モル電気伝導率と電解質濃度の平方根の関係 図2.4 大堺ら「ベーシック電気化学」(化学同人)

Ionic conductivity (o)




Ionic conductivity (o)





モル電気伝導率と電解質濃度の平方根の関係 図2.4 大堺ら「ベーシック電気化学」(化学同人)

Ionic conductivity (σ)





Ionic conductivity (σ)

イオン	$^{\lambda_{+}/10^{-4}S} \cdot _{m^{2}\cdot mol^{-1}}$	$u_{+}/10^{-8} \text{m}^{2} \cdot \text{s}^{-1} \cdot \text{V}^{-1}$	イオン	$^{\lambda_{-}/10^{-4}S} \cdot ^{\bullet} \text{m}^{2} \cdot \text{mol}^{-1}$	$u_{-}/10^{-8} \text{m}^2 \cdot \text{s}^{-1} \cdot \text{V}^{-1}$
H+	349.82	36.3	OH-	198.0	20.5
Li+	38.69	4.01	Cl-	75.23	7.91
Na+	50.11	5.19	Br-	78.4	8.01
K+	73.52	7.61	I-	76.8	7.95
Ag+	61.92	6.41	NO ₃ -	71.44	7.40
NH ₄ +	73.4	7.60	HCO ₃ -	44.5	4.61
Ca2+	59.50	6.16	CH ₃ COO-	40.9	4.23
Mg2+	53.06	5.50	SO ₄ 2-	79.8	8.27


Where v_+ and v_- are the number of cations and anions per formula unit of electrolyte respectively, λ_+^{∞} and λ_-^{∞} are the molar conductivities of the cation and anion at infinite dilution respectively.

Conductivity (o)





reaction



Chemical reaction

Electrochemical reaction


$$A \leftrightarrow B$$

$$2H_2 + O_2 \rightarrow 2H_2O$$


$$O_X + ne^- \leftrightarrow R_{ed}$$

Oxidized form Reduced form $2H_2 \rightarrow 4H^+ + 4e^-$
 $O_2 + 4H^+ + 4e^- \rightarrow 2H_2O$

Chemical reaction



Electrochemical reaction



Chemical potential

$$\mu_i = \mu_i^{\circ} + RT ln a_i$$
a; activity of the species

Electrochemical potential

$$\widetilde{\mu_{i}} = \mu_{i}^{\circ} + RT ln a_{i} +$$


$$\widetilde{\mu_{i}} = \mu_{i} +$$

$$(Eq 3.2)$$


$$(Eq 3.3)$$

 \emptyset : electric potential Z_iF : the charge of one mole of ions

The electrochemical potential was introduced by *Guggenheim*. The potential $\widetilde{\mu_i}$ is the sum of the chemical potential μ_i and the electric potential $z_i F \emptyset$.



				<i>E</i> °'/V
<u>1</u>	$O_2 + 4H^+ + 4e^-$	++	2H ₂ O	+0.82
2	$2HNO_3 + 10H^+ + 10e^-$	+ +	$N_2 + 6H_2O$	+0.80
3	$CO_2 + 8H^+ + 8e^-$	**	CH ₄ (メタン) + 2H ₂ O	-0.25
4	$NAD^{+} + H^{+} + 2e^{-}$	**	NADH .	-0.32
5	HCOOH (蟻酸) + 4H ⁺ + 4e ⁻	+ +	CH_3OH ($\mathcal{A}\mathcal{P}\mathcal{I}-\mathcal{V}$) + H_2O	-0.36
6	グルコン酸 + 2H* + 2e-	**	グルコース(ブドウ糖)+ H ₂ O	-0.36
7	$CO_2 + 6H^* + 6e^-$	*	CH_3OH (メタノール) + H_2O	-0.40
8	CH ₃ COOH (酢酸) + 4H ⁺ + 4e ⁻	•	CH ₃ OH (エタノール) + H ₂ O	-0.40
L 9	2H ⁺ + 2e ⁻	++	H_2	-0.41
10	$6CO_2 + 24H^+ + 24e^-$	**	グルコース(ブドウ糖)+ 6H ₂ O	-0.43
11	$2CO_2 + 12H^+ + 12e^-$	**	C_2H_5OH (エタノール) + $3H_2O$	-0.50



External circuits (Electron) Electrolyte(Ion conductivity)

Resistance

External circuits (Electron) Electrolyte(Ion conductivity) Electrode(Ion)

Electron

Ion

Cathode

Voltage


Power supply Electrochemical potential (in battery)


Current


Faradaic or non-faradaic reaction

Electrolysis of water

 $2H_2O \rightarrow 2H_2 + O_2$








Reference electrode(参照電極)

Standard hydrogen electrode




$$2H^+(aq) + 2e^- \rightleftarrows H_S(g)$$

$$RT \qquad a...$$


$$E = E^{0} + \frac{RT}{F} ln \frac{a_{H+}}{(p_{H2}/p^{0})^{1/2}}$$

Ag/AgCl electrode



$$AgCl + e^{-} \rightleftharpoons Ag + Cl^{-}$$

$$E = E^{0} + \frac{RT}{F}lna_{Cl^{-}}$$



Electrochemical potential


Voltage

Power supply
Electrochemical potential
(in battery)


Current

Faradaic or non-faradaic reaction


Electrolysis of water $2H_2O \rightarrow 2H_2 + O_2$



Electrolysis of water




Electrolysis of water




Non-faradic reaction

Potential and ions distribution away from a charged surface



The Helmholtz model




Gibbs-Helmholtz equation Young-Helmholtz theory Helmholtz-Thevenin's theorem Helmholtz coil

Hermann Ludwig Ferdinand von Helmholtz

$$\emptyset = \emptyset_0 \left(1 - \frac{1}{x_H} X \right) \qquad (Eq 5.3)$$

Linear potential drop from the surface to the Helmholtz layer (x_H)

The Helmholtz model





Gibbs-Helmholtz equation

Young-Helmholtz theory

Helmholtz-Thevenin's theorem


Helmholtz coil

Hermann Ludwig Ferdinand von Helmholtz

$$\frac{C_H}{A} = \frac{dq}{dE} = \frac{\varepsilon_H}{x_H} \quad \text{Helmholtz model}$$
(Eq 5.4)

Where ε_H is the Helmholts permittivity, but the precise significance that attaches to each of these quantities separately is open to interpretation.

The Helmholtz model





Gibbs-Helmholtz equation
Young-Helmholtz theory
Helmholtz-Thevenin's theorem
Helmholtz coil


Hermann Ludwig Ferdinand von Helmholtz

$$\frac{C_H}{A} = \frac{dq}{dE} = \frac{\varepsilon_H}{x_H}$$
 (Eq 5.4)

Does not take into account

- Thermal motion
- Ion diffusion
- Adsorption on the surface
- Solvent/surface interaction

The Gouy-Chapman model



Distance from electrode surface Figure 5.5

$$\emptyset = \emptyset_0 e^{-\kappa X} \qquad {}^{(Eq 5.5)}$$

Exponential potential decrease

The ions are mobile in the electrolyte (diffusion, electrostatic forces)


Boltzmann statistical distribution

Debye length $(1/\kappa)$: "thickness of diffuse double layer"

Account

- Thermal motion
- Ion diffusion

The Sterm model




Distance from electrode surface Figure 5.7

Stern recognized that the experimental capacitance results were better matched by a melding of the Helmholtz and Gouy-Chapman models, some of the counterions being in a diffuse zone and some in a compact layer immediately adjacent to the interface.

$$\emptyset = \emptyset_0 \left(1 - \frac{1}{x_H} X \right) \quad (Eq 5.12)$$

$$\emptyset = \emptyset_{St} e^{-\kappa(X - x_H)} \qquad (Eq 5.13)$$

The Sterm model




Capacitances arising from the two regions would be in series and so the overall capacitance would be calculable from the formula

$$\frac{1}{C_{S}} = \frac{1}{C_{H}} + \frac{1}{C_{GC}}$$

$$= \frac{x_{H}}{A\varepsilon_{H}} + \frac{\sqrt{RT/2F^{2}\varepsilon c}}{A\cosh\{F(E - E_{ZC})/RT\}}$$
Stern model (Eq 5.14)

The Sterm model




The permittivity enters equation 5.14 twice, but its significance differs between the two instances. The permittivity ε in the disordered diffuse zone will be close to that of pure water, about $79\varepsilon_0$. However, the permittivity ε_H in the compact layer is that of water-plus-ions confined in a narrow region, compressed, and ordered by an intense local field; estimates suggest that the permittivity here is much lower, perhaps as small as $5\varepsilon_0$.

$$\frac{1}{C_S} = \frac{1}{C_H} + \frac{1}{C_{GC}}$$


$$= \frac{x_H}{A\varepsilon_H} + \frac{\sqrt{RT/2F^2\varepsilon c}}{A\cosh\{F(E - E_{ZC})/RT\}}$$
Stern model (Eq 5.14)

Bockris-Devanathan-Müller(BDM)model




In 1963 J. O'M. Bockris, M. A. V. Devanathan and Klaus Müller proposed the BDM model of the double-layer that included the action of the solvent in the interface. They suggested that the attached molecules of the solvent, such as water, would have a fixed alignment to the electrode surface. This first layer of solvent molecules displays a strong orientation to the electric field depending on the charge. This orientation has great influence on the permittivity of the solvent that varies with field strength. The inner Helmholtz plane (IHP) passes through the centers of these molecules. Specifically adsorbed, partially solvated ions appear in this layer. The solvated ions of the electrolyte are outside the IHP. Through the centers of these ions pass the outer Helmholtz plane (OHP). The diffuse layer is the region beyond the OHP. The BDM model is currently the most commonly used.


Application of double layer



Electrolysis of water




Reaction at the electrode



Kinetic current

$$O_X + ne^- \stackrel{
u_{O_X}}{\underset{
u_{Red}}{\rightleftharpoons}} R_{ed} \qquad \stackrel{
u_{O_X} = k_{O_X} C_{O_X}(0,t)}{
v_{Red} = k_{Red} C_{Red}(0,t)}$$




Butler-Volmer equation

$$\begin{split} I &= -nF(v_{Ox} - v_{Red}) \\ &= -nFk^0 \left(C_{O_x}(0,t) exp(-\alpha nF(E-E^0)/RT) \right) \\ &- \left(C_{Red}(0,t) exp((1-\alpha)nF(E-E^0)/RT) \right) \\ k_{ox} &= k^0 exp(-\alpha nF(E-E^0)/RT) \\ k_{Red} &= k^0 exp((1-\alpha)nF(E-E^0)/RT) \end{split}$$


Diffusion-limited current

Fick's first law


$$J_{i} = -D_{i} \frac{dC_{i}}{dx} \longrightarrow I_{a} = nFD_{R_{ed}} \frac{dC_{R_{ed}}}{dx}$$



Diffusion-limited current




Electrolysis of water



Analysis of electrode reaction


- Oxidation reduction potential (ORP)
 Open circuit potential (OCP)
- Potential step voltammetry Linear sweep voltammetry Cyclic voltammetry
- AC impedance measurement

Oxidation reduction potential (ORP) Open circuit potential (OCP)



Reference electrode(参照電極)


Standard hydrogen electrode



$$2H^+(aq) + 2e^- \rightleftharpoons H_s(q)$$

$$E = E^{0} + \frac{RT}{F} ln \frac{a_{H+}}{(p_{H2}/p^{0})^{1/2}}$$

Ag/AgCl electrode




$$AgCl + e^- \rightleftharpoons Ag + Cl^-$$

$$E = E^0 + \frac{RT}{F} lna_{Cl} -$$

Oxidation reduction potential (ORP) Open circuit potential (OCP)

Working electrode



Reference electrode

Constant potential

Standard hydrogen electrode (SHE)

Ag/AgCl electrode

Reversible hydrogen electrode (RHE)


Saturated calomel electrode (SCE)

Analysis of electrode reaction

- Oxidation reduction potential (ORP)
 Open circuit potential (OCP)
- Potential step voltammetry Linear sweep voltammetry Cyclic voltammetry
- AC impedance measurement

Voltammetry

Analysis of electrochemical reaction at the Working Electrode (**WE**)



Voltammetry

Current: 1 '


Measurement of current as a function of potential applied by a potentiostat (a three-electrode system)

CE: Counter electrode


ctrode system)

WE: Working electrode

RE: Reference electrode




Potentiostat system




The system basically maintains the POTENTIAL(ΔE) of the **WE** at a constant level with respect to the **RE** by adjusting the CURRENT (I) at the **CE**


Analysis of electrochemical reaction at the **WE**



Linear sweep voltammetry



Linear sweep voltammetry



Nernst equation


$$E = E^{0} + \frac{RT}{nF} ln \frac{[Fe^{2+}]}{[Fe^{3+}]}$$

POTENTIAL - CONCENTRATION


Current increase from V_1 to E_p^0

Rate of electron transfer is fast vs voltage sweep

Linear sweep voltammetry



Linear sweep voltammetry





- Each curve: same form
- · Total current increases with increasing scan rate
- Position of the current maximum remains the same potential

Linear sweep voltammetry

Note: With stirring Steady state conditions:

The influx of Fe^{2+} does not change in time.






- No peak
- $i_{limiting} \propto [Fe^{2+}]$ $i_{limiting}$ is constant


Fe²⁺ constantly replaced by ready influx from bulk solution.

Kinetic current

Cyclic voltammetry




Scan is reversed when voltage reaches one end.




Forward scan: Fe²⁺ → Fe³⁺ +e⁻

Reversed scan: Fe³⁺ +e⁻ → Fe²⁺

Cyclic voltammetry






$$E_{midpoint} = \frac{(E_p^a + Epc)}{2} = E^0 + \frac{RT}{nF} ln \frac{[D_R^{1/2}]}{[D_0^{1/2}]}$$

Same value when the pH is changed by 1.0 pH.

$$\Delta E_p = |E_p{}^a - E_p{}^c| = 2.3 \frac{RT}{nF} = \frac{59}{n} mV \ (at \ 289K)$$

Cyclic voltammetry


Analysis of electrochemical reaction at the Working Electrode (WE)




Analysis of electrode reaction


- Oxidation reduction potential (ORP)
 Open circuit potential (OCP)
- Potential step voltammetry Linear sweep voltammetry Cyclic voltammetry
- AC impedance measurement

AC impedance system



AC impedance system





Transfer function (伝達関数)

Frequency transfer function

$$G(jw) = \frac{Y(jw)}{X(jw)} = \alpha + j\beta$$

$$j: imaginary unit$$


Resistor

$$- \nearrow \searrow - \qquad I = \frac{V}{R} \qquad Z_R = R$$
 Capacitor

$$I = \frac{V}{R}$$


Impedance Im: imaginary part







$$I = C \frac{dV}{dt}$$


Series R-C circuit







Parallel R-C circuit





Combining impedances in series and parallel





33